

## **Raised Vegetable Garden Installation Guide**

**1000mm x 1000mm x 400mm**

***Thank you for purchasing a Recycled Plastic Raised Vegetable Garden from Cosset Industries. Your Vegetable Garden will give you many years of enjoyment through growing your own vegetables.***

### **Items Needed To Install Your Raised Vegetable Garden Bed Include:**

**2 x 10mm Open Ended or Ring Spanners  
1 x Tape Measure  
1 x Spirit Level  
1 x Friend or Relative – It is a lot easier with two people**

### **Items Included In Your Raised Vegetable Garden Carton Include:**

**4 x 1000mm Side Planks  
4 x 1000mm End Planks  
4 x 800mm Corner Vertical Posts  
32 x Galv Dipped M6x100 Bolts, Nuts & Washers**

***Before you begin to install your garden you need to determine what surface it is going to be placed on.***

***To install on a hard surface such as concrete, begin by cutting your vertical posts in half, using only the pre-drilled top sections for the installation. Otherwise, begin with step one below. Be sure to recycle your off cuts or put them to good use elsewhere in the garden.***

- |                |   |
|----------------|---|
| <b>STEP 1)</b> | <b>Lay each bottom plank out at your desired installation location</b>  |
| <b>STEP 2)</b> | <b>Dig holes at least 400mm deep at each point where a vertical post is located</b>   |
| <b>STEP 3)</b> | <b>Bolt the end bottom plank to the two vertical posts that will support it, followed by the top end plank. Make sure the other side of the vertical post is lined up to accept the side planks. Repeat this step at the other end.</b> |
| <b>STEP 4)</b> | <b>Once your ends are assembled, whilst holding one end and one bottom side plank up, simply bolt together. This may be a tight fit. If so, tap bolts in using a hammer. Repeat this step with the top plank, then the other side.</b>  |
| <b>STEP 5)</b> | <b>Once your Raised Garden Bed is level, simply fill in holes supporting the Vertical Posts with back fill.</b>   |